


**VIBRATOR HEAD PARTS**



**Note:** Head Repair Kit shown includes 2 Front Bearings, 2 Rear Bearings and Seal Assembly.

Head sizes are nominal, actual sizes may vary 1/16 to 1/8 Inch.

HEAD SIZE	43 - Steel Tip		43FS - Form Saver Tip		44 - Housing		45 - Rotor		52 - Head Repair Kit	
	Part No.		Part No.		Part No.		RH Part No.	LH Part No.	Part No.	
3/4"	390A1		390K1		367A1		496A1	496A2	225A1	
1"	390B1		390L1		367B1		496B1	496B2	225B1	
1-1/4"	390C1		390M1		367C1		496C1	496C2	225C1	
1-1/2"	390D1		390N1		367D1		496D1	496D2	225D1	
1-3/4"	390E1		390P1		367E1		496E1	496E2	225E1	
2"	390F2(RH)		390R2(RH)		367F2(RH)		496F1	--	225F1	
	390F3 (LH)		390R3 (LH)		367F3 (LH)		--	496F2		
2-1/2"	390G1		390S1		367G1		496G1	496G2	225G1	

For 50 & 51 Parts - See Next Page.

NOTE: ALL REQUIRED HARDWARE IS INCLUDED WITH EACH PART.